

Introduction.

This manual is intended as a guide how to quickly setup your OMC-045-datalogger with OMC-Programmer. For more detailed information we refer to the **help files**, which you can access via the [F1] function key anywhere in OMC-programmer.

1. Check required items:

- OMC-045-II
- SD-card (included)
- USB cable (included)
- GSM/GPRS antenna (included)
- *SIM card*
- *Optional GPS antenna*
- [OMC-Programmer](#)
- *Suitable sensors*
- *Suitable power supply*



Important notes:



SD-Card: The included SD card is specially formatted for the OMC-045-II
DO NOT FORMAT THE CARD VIA WINDOWS!
Leave the switch to the 'LOCK' (= Write Protect) position whenever used in a pc.



SIM card: Check the card in a phone, make sure the PIN code is disabled.
Test if GPRS is available.



BOTH CARDS SHOULD ONLY BE PLACED OR REMOVED WHEN THE POWER IS OFF!

Power Supply: If the sensors are powered via the OMC-045-II, make sure the PSU (Power Supply Unit) is suitable for both the OMC-045-II and the sensors.
Else the sensor should be powered by a separate PSU.



The output voltage of the OMC-045-II is identical to the PSU!

2. Connect all sensors & antenna's

- Use delivered diagram or use the connectors layout in the appendix to determine the correct connections.
- Connect the power supply
- Do not connect the OMC-045-II by USB before you installed OMC-programmer

3. Install OMC-programmer

- Check the support page of www.observator.com ([Obsermet Meteo & Hydro](#)) for the latest version.
- Install OMC-programmer on your pc, this will also install the required USB driver

4. Connect the OMC-045-II via the USB cable to your pc

- Start OMC-programmer
- **Configure Substation**
- **Read Configuration From Device**
- **Use Direct communication**
- Communication protocol: 'OMC-045 II / OMC-410
- Select Com-port: COM xx (usually the highest number)*
- **Read Configuration From Substation**
- Baudrate: 19200
- 'OK'



Sensors:

Select the connected sensors, use **Advanced** to change port numbers / baudrate etc.

Parameters:

Select which parameters you want to log


Input (Tag list):

Change tag names, log interval, alarm interval etc



Substation:

Set Substation name / System Id & Data send time Delay (normally 0)




Data Output:

Select Outputs, use **Advanced** to set intervals

Modem (Email/FTP and TCP/IP through GPRS):

Set your provider details, ftp server or emails settings.



NOTE: FTP and EMAIL require different firmware!

Alarm Handling:

Set sms alarm numbers and sms service center number.

Save configuration:

Save your configuration to Substation and File as backup.



* If you don't know the correct comport, disconnect the USB cable, select 'Cancel' and select 'Use direct communication' again. Note which comports are available. Reconnect the USB cable, select 'Cancel' and select 'Use direct communication' again. The 'new' comport is the OMC-045-II

Troubleshooting

From the **Main Menu** you can select **Read Actual Values** to view if anything is read. Also through the **Main Menu** you can select **Maintenance** (password is 'manager') By using the **Terminal Window Substation** you can monitor the sensor data which is read in the OMC-045-II. This will help you identify wrong connections, port numbers & baudrate.

NOTE: COM numbers are not identical to Port numbers, select Port 1 .. 4 to monitor your inputs!

Frequent Asked Questions

1. I receive no data

- Check if data is stored on the SD card (if not see 2.)
- Check if your Sim card is working (check GPRS with the card in a phone)
- Check your configuration (GPRS, FTP or Email settings, time delay in Substation etc.)
- Correct Firmware? Email & FTP require different firmware, check your version in the **Advanced Config** and compare the 'Software Build' with the versions on our support page at www.observator.com/instruments/meteo-hydro/

2. My data is not stored on the SD card

- SD card correctly fitted?
- Card correctly formatted (not by Windows!)?
- Check your configuration
- Check if any data is received via the Terminal Window
- Replace SD card if the above is OK

3. Can I read the SD card direct via a PC?

- Yes, you can so via the OMC-programmer main menu:
- Option 1 is via the OMC-045-II **Download Data from Substation** which is slow, but gives you the option to select the type of data, date and put it in a comma separated file.
- Option 2 is via a SD-card reader. First make sure the SD-card is write protected! Via **Read Data from SD Card** you can read all data from the card. At the moment you can not select the data and date, but it is fast.

4. What is the password for Maintenance & Advanced Config?

- the password is 'manager'

5. I'm missing some data from my Sontek (or other serial device).

- Make sure you have the latest firmware, older version can not handle large strings well.
- Check our support page for the latest version

6. I have checked all above, but still can't configure my OMC-045-II the way I want or I have some other questions.

- Contact our support desk at service@observator.com and include the following information:
 - o Serial number
 - o Firmware version (Software Build in **Advanced Config**)
 - o OMC-programmer version number
 - o Your configuration XML-file
 - o And your question or problem...


Appendix

Connections:

GPS antenna
 GPRS antenna

FUSE

X1 USB mini-B connector.
 SIM card holder
 SD card holder
 X2
 X3
 X4



X2 Connector Layout: power inputs, power outputs, and display

terminal	name	Description
X2.1	GND	Power supply input for 10-30V (not used for OMC-045-II-regen)
X2.2	VIN	
X2.3	GND	Switched power supply output for sensors (output 1)
X2.4	VOUT1+	Terminals X2.4 and X2.6 are internally interconnected
X2.5	GND	
X2.6	VOUT1+	
X2.7	GND	Switched power supply output for sensors (output 2)
X2.8	VOUT2+	Terminals X2.8 and X2.10 are internally interconnected
X2.9	GND	
X2.10	VOUT2+	
X2.11	GND	Connection for external red LED. LED function is identical to the LED on the top of the OMC-045-II
X2.12	LEDOUT	
X2.13	GND	Reserved for connections of an external display
X2.14	VOUTCONT	Data logger → Display
X2.15	TXDIS	Data logger ← Display
X2.16	RXDIS	

Warning: The alarm outputs are open drain output, which means that they are internally connected to GND (through a FET); an indicating device should be connected between DOUT1 or DOUT2 and an external supply voltage of max 20V



X3 Connector Layout: digital inputs and communication ports

terminal	name	Description
X3.1	GND	Status input for connection of a passive switch
X3.2	DIN1	
X3.3	GND	Rain gauge input, Pulse input for connection of passive switch sensors
X3.4	DIN2	
X3.5	GND	RS232 PORT 1
X3.6	TX1	Data logger → Sensor
X3.7	RX1	Data logger ← Sensor
X3.8	GND	RS232 PORT 2
X3.9	TX2	Data logger → Sensor
X3.10	RX2	Data logger ← Sensor
X3.11	GND	RS232 PORT 3
X3.12	TX3	Data logger → Sensor
X3.13	RX3	Data logger ← Sensor
X3.14	GND	RS232 PORT 4 or RS422/RS485
X3.15	TX4 / A	Software-selected in the configuration
X3.16	RX4 / B	Tx Data logger → Sensor Rx Data logger ← Sensor

X4 Connector Layout: analogue inputs and alarm outputs

terminal	name	Description
X4.1	GND	4-20 mA input channel A1
X4.2	A11	
X4.3	GND	4-20 mA input channel A2
X4.4	A12	
X4.5	GND	4-20 mA input channel A3
X4.6	A13	
X4.7	GND	4-20 mA input channel A4
X4.8	A14	
X4.9	GND	Potentiometer input channel A5
X4.10	A15	Max 2,5 Volt in
X4.11	VREF	2,5 Volt out
X4.12	GND	0-10V input channel A6
X4.13	A16	
X4.14	DOUT1	Alarm outputs DOUT1 and DOUT2. These are open drain outputs.
X4.15	DOUT2	
X4.16	GND	Max 20V